


Sizing Guide

For Use With
Amara View


How to Use:

1. Find a ruler and a mirror.
2. Measure from the base of your nose, to the tip. Note your length measurement.
3. Consult sizing guide below.

Note: Do not compress the upper lip. Gently place the edge of your ruler on the skin. Do not press down as this will contribute to an inaccurate measurement.



Measurement Taken Below the Nose



Length Measurement

Size Guide:

Length Measurement

Small:	0 - 1.0 Inches	0 - 2.5 cm
Medium:	1.0 - 1.5 Inches	2.5 - 3.8 cm
Large:	1.5 + Inches	3.8 + cm

Note: We find these measurements work with about 80% of our clients. Head shape, nose shape and nose density is also a factor. In person fitment is always recommended.